



# HUMIDIFIER HEATER WIRE ADAPTERS



# **Humidifier Heater Wire Adapters**

HWA Series Heater Wire Adapters are used to provide electrical energy from the humidifier to the heater wire of disposable or reusable heated breathing circuits. Dual or Single limb Adapters are available. Regular HWA Series Heater Wire Adapters do not have surge and over-current protection circuit. Prefer SOCP type HWA cables for these features.

circuit. Prefer SOCP type HWA cables for these features.

▼ Breathing Circuit Connector

▼ Device Side Monitor

REF: HWA-001 (OEM P/N F&P 900MR801, DRÄGER 8414992)
 Heater Wire Adapter for RT Series disposable heated breathing circuits. For use with MR850, HC550 Humidifiers.



REF: HWA-002 (OEM P/N F&P 900MR800, DRÄGER MP01006)
 Heater Wire Adapter for RT Series disposable dual heated breathing circuits. For use with MR850, HC550 Humidifiers.



REF: HWA-003 (OEM P/N F&P 900MR858, DRÄGER 8414968)
 Heater Wire Adapter for reusable heated breathing circuits with LEMO connector. For use with MR850, HC550 Humidifiers.



REF: HWA-004 (OEM P/N F&P 900MR856)

Heater Wire Adapter for reusable dual heated breathing circuits with LEMO connector. For use with MR850, HC550 Humidifiers.




REF: HWA-005 (OEM P/N F&P 900MR859, DRÄGER MP01001)
 Heater Wire Adapter for disposable heated breathing circuits with Molex connector. For use with MR850, HC550 Humidifiers.



REF: HWA-006 (OEM P/N F&P 900MR855)
 Heater Wire Adapter for disposable dual heated breathing circuits Molex connector. For use with MR850, HC550 Humidifiers.

# **Humidifier Heater Wire Adapters**



# **Humidifier Heater Wire Adapters**

REF: HWA-001/SOCP (OEM P/N F&P 900MR806)

Heater Wire Adapter for RT Series disposable heated breathing circuits. For use with MR850, HC550 Humidifiers.



REF: HWA-002/SOCP (OEM P/N F&P 900MR805)

Heater Wire Adapter for RT Series disposable dual heated breathing circuits. For use with MR850, HC550 Humidifiers.



REF: HWA-003/SOCP

Heater Wire Adapter for reusable heated breathing circuits with LEMO connector. For use with MR850, HC550 Humidifiers.



REF: HWA-004/SOCP

Heater Wire Adapter for reusable dual heated breathing circuits with LEMO connector. For use with MR850, HC550 Humidifiers.



REF: HWA-005/SOCP

Heater Wire Adapter for disposable heated breathing circuits with Molex connector. For use with MR850, HC550 Humidifiers.



REF: HWA-006/SOCP

Heater Wire Adapter for disposable dual heated breathing circuits Molex connector. For use with MR850, HC550 Humidifiers.

### Heater Wire Breathing Circuit Connectors



RT / F&P Type (Disposable)



RT / F&P Type (Disposable)



Molex Type (Disposable)



LEMO Type (Reusable)

### FMT is registered trademark of Metko Ltd.



### **Headquarter & Factory**

İvedik O.S.B. Ağaç İşleri Sanayi Sit. 1354. Cad. 1358.Sok. No:9 06378 Yenimahalle

### **ANKARA / TÜRKİYE**

Tel (pbx): +90 312 387 12 46 Fax: +90 312 387 12 51

### **Branch**

Atatürk Mah. Sedef Cad. 38.Ada Ata Plaza 3-5 Blokları Kat:2 No:57 34758 Ataşehir

### **ISTANBUL / TÜRKİYE**

Tel (pbx): +90 216 455 91 21 Fax: +90 216 455 48 24

### www.metkoltd.com

Other products, logos and company names mentioned herein may be trademarks of their respective owners and are not to be taken as an endorsement of affiliation with FMT®. The information in this catalogue has been carefully checked and it is believed to be accurate. Images in this catalogue are representative of items offered. Actual product may have slight visual differences. In the interest of continued product development, Metko reserves the right to make changes and improvements to this catalogue and the product it described any time, without notice or obligation.